

## Long Bone Pain Protocol (Lower Extremity)

**Reviewed By:** Lawrence Tang, MD

**Last Reviewed:** May 2022

**Contact:** (866) 761-4200, Option 1

### General parameters (1.5 T magnets):

For all T1 sequences, please keep TE below 20 (between 10 and 15 if possible); TR 500-600.

For all T2 FS sequences, use equivalent of FSE/TSE. TE of mid to upper 50's is the most ideal for Siemens, 60-65 for GE, and ~ 60 for Toshiba.

It is important to have TE long enough for T2 weighting but not so long that it is signal starved.

For STIR, TI = ~ 135

Unilateral for all of the following:

- ax T1 – unilateral
- ax T2 FS – unilateral
- cor T1 –unilateral
- cor T2 FS or STIR – unilateral
- sag T2 FS or STIR – unilateral