

Osteomyelitis Hindfoot or Ankle (Ulcer at Dorsal or Plantar Hindfoot)

Reviewed By: Lawrence Tang, MD

Last Reviewed: May 2022

Contact: (866) 761-4200, Option 1

General parameters (1.5 T magnets):

For all T1 sequences, please keep TE below 20 (between 10 and 15 if possible); TR 500-600.

For all T2 FS sequences, use equivalent of FSE/TSE. TE of mid to upper 50's is the most ideal for Siemens, 60-65 for GE, and ~ 60 for Toshiba.

It is important to have TE long enough for T2 weighting but not so long that it is signal starved.

For STIR, TI = ~ 135

The purpose of this seemingly complicated approach to osteomyelitis is to streamline the protocol so we can perform the exams on a consistent basis to obtain adequate diagnostic information with a reasonable amount of scanning time.

For all osteomyelitis cases, post-contrast sequences are needed for evaluation of bone viability.

If intravenous contrast cannot be administered due to severe renal insufficiency or allergy, please refer to routine protocol to scan the patient.

Ulcers should be marked before scanning is initiated.

Please acquire sequences in the order listed in the protocol.

If there is difficulty completing the last post-contrast sequence (e.g. pt. motion, pt. pain, scanner shut down etc.), there is no need to repeat the specific sequence.

Setup and Imaging Planes:

- Setup as ankle MR:
- ax – axial to tibia/fibula
- cor – coronal distal tibial sigmoid notch
- sag – perpendicular to coronal plane




Imaging Sequences:

- cor T1
- cor T2 FS
- sag T1
- sag STIR
- sag pre contrast T1 FS
- sag post contrast T1 FS
- cor post contrast T1 FS



 253-761-4200

 PO Box 1535
Tacoma WA 98401

 tranow.com